



WIRING DIAGRAMS FOR AC HOUR METER APPLICATIONS




Single-phase 120V System: 2-Wire

Connect one terminal to power wire; opposite terminal to neutral wire.




Single-phase 120V/240V System: 3-Wire

Connect one terminal to power wire; opposite terminal to neutral wire.




Three-phase 120V/208V System: 4-Wire

Connect one terminal to any one power wire; opposite terminal to neutral wire.




Three-phase 120V/240V System: 4-Wire Delta with a high leg

Connect one terminal to any of two available 120V power wires; opposite terminal to neutral wire. Hour meter is not to be connected to the high leg.




Single-phase 240V System: 2-Wire

Connect one terminal to power wire; opposite terminal to neutral wire,




Single-phase 120/240V System: 3-Wire

The hour meter is to be connected across two high sides of the line. The meter is not to be connected to the neutral wire.



Three-phase 240V System: 3-Wire Delta

Hour meter to be connected across any two power lines.



Three-phase 120/240V System: 4-Wire Delta with a high leg

Connect one terminal to any one power wire; opposite terminal to be connected to one of two remaining power lines. Hour meter is not to be connected to the neutral wire.